

BINDER FOOT

1. MACHINE SETTING

Straight stitch (needle position : M) or three point zigzag stitch.

Thread tension: 3 to 5

- * The upper thread should be put through the needle hole on the binder foot from the upside to the downside, then pulled under the foot.


2. TAPE FOR BINDING

Most binding tape sold in stores has folded edges.

When sewing a garment, you may want to use the same material that the garment is made of as your binder tape. The way to use both kinds of tape is shown below.

3. HOW TO BIND WITH PRE-FABRICATED BINDING TAPES

- ① Cut the end of the tape diagonally, and insert it into the appropriate length hole, chosen out of 5 on the conical tape guide of the binder foot.
- ② Pull out the end toward the needle hole of the foot with a needle or a stiletto.
- ③ Insert the edge of the cloth into the opening of the guide.
- ④ Sew slowly while guiding the edge of the cloth with your middle finger on the finger rest and guiding the binding tape so that it passes through the conical tape guide properly with your right hand.



4. HOW TO BIND WITH YOUR HAND-MADE TAPE

- ① Make some 25mm (1inch) wide strips in the desired length. Cut the end of the strip diagonally, and insert the end into the inside of the conical tape guide. Then pull out the end toward the needle hole of the foot with a needle or a stiletto.
- ② Insert the edge of the cloth into the opening of the guide.
- ③ Sew slowly while guiding the edge of the cloth with your middle finger on the finger rest and guiding the binding tape so that it passes through the conical tape guide properly with your right hand.

