

How to use a Jean-a-ma-jig™


What is a Jean-a-ma-jig™?

It is a sewing tool designed to aid in stitching over thick seams. It helps prevent skipped stitches and broken needles caused by uneven fabric surfaces. Perfect for topstitching and hems on jeans, costumes, towels, quilts, upholstery and home dec projects. Works on any sewing machine!

Item #915

What are the parts?

Each package includes one Jean-a-ma-jig™.



How to you use a Jean-a-ma-jig™?

1. Press and pin your hem. Begin stitching, stopping 3/4" before a thick seam. With needle in the down position, raise presser foot.
2. Slide the Jean-a-ma-jig under back of presser foot with needle in the center of slot, until it rests against edge of thick seam allowance. Lower presser foot **(A)**.
3. Slowly stitch across seam and off edge of the Jean-a-ma-jig. With needle in the down position, raise presser foot and remove Jean-a-ma-jig.
4. Turn Jean-a-ma-jig and slide it under front of presser foot **(B)**. Lower presser foot and continue stitching onto Jean-a-ma-jig.
5. Stop when presser foot is completely on the Jean-a-ma-jig and lower needle into the fabric. Raise presser foot and remove Jean-a-ma-jig. Continue sewing, repeating the process at each seam.

