



Spool Holder (Special)

Sometimes, a large spool will not fit on your horizontal spool pin with enough room for the spool holder to attach properly. This Horizontal Spool Holder allows the spool to be held tight to your spool pin without falling off or creating a gap.


Simply put your thread on the horizontal spool pin the way that you normally would. Then place the Spool Holder onto the spool pin and up against your thread to keep it from moving while you are sewing.

Fits all Janome Sewing Machines with Horizontal Spool Pin.

SPPOOL HOLDER (SPECIAL)	202-233-006
----------------------------	-------------




Fits Perfectly.



Has a gap.

When using a larger spool of thread, the traditional spool cap will have a gap. This will make the thread wobble while sewing.



Falls off.

If you don't use a spool cap that fits properly, your thread will fall off the spool pin

Believe in Your Creativity
JANOME

Join us!

www.janome.com

